



Cleaning Guide



Pattern: Silica

Color: Alfresco

Product Number: 09143297

Content: 100% Silicone

WS General Recommendations

- Clean with water-based foam or upholstery cleaner or dry cleaning solvents
- Do not saturate with liquids
- Do not get the furniture wet

Regular Maintenance

- Clean monthly with a clean, soft, colorfast, damp, soapy cloth or sponge and rinse with clean water

Stain Treatment and Spot Cleaning

A professional cleaning service is recommended

Treat stains quickly

- It will become increasingly difficult to remove the longer a stain is allowed to set
- Pretest any cleaning method or agent in a small hidden inconspicuous area
- Several less concentrated applications are less damaging than one concentrated application

Remove fluids immediately by blotting with a clean, colorfast, absorbent cloth

Flush stain with water and dry with clean cloth

Remove solid or semi-solid substances

- Using a flat object, remove as much of the stain as possible
- After removal, vacuum thoroughly using the proper attachments before cleaning with an agent

Abrasive household cleansers and steel wool should be avoided



Cleaning Guide

- Step 1:** Silica can be cleaned very simply with a clean, soft, colorfast, damp cloth or sponge
- Step 2:** If stain persists, wipe using a clean, soft, colorfast, damp, soapy cloth or sponge and rinse with clean water
- Step 3:** If stain persists, consult the chart below
If using bleach, up to a 4:1 water to bleach solution may be used
If using other agents, please follow manufacturers recommended instructions
- Step 4:** Thoroughly rinse with water and pat dry

Silica / Silica Tech / Silica Leather				
Stain	Water	Solvent	Bleach	Virox
Paint / Ink	5/5	5/5	5/5	5/5
Permanent Marker	5/4.5	5/5	5/5	5/5
Ketchup, Mustard	5/2.5	5/2.5	5/5	5/5
Coffee	5/4	5/4.5	5/5	5/5
Suntan Lotion	5/5	5/5	5/5	5/5
Blood, Urine, Betadine	5/5	5/5	5/5	5/5
Lipstick, Mascara	5/5	5/5	5/5	5/5
Chocolate	5/5	5/5	5/5	5/5
Denim	5/5	5/5	5/5	5/5

Rating System

- Class 5** - No evidence of stain present
- Class 4** - Slight evidence of stain present
- Class 3** - Noticeable evidence of stain present
- Class 2** - Considerable evidence of stain present
- Class 1** - Excessive evidence of stain present

Bleach Cleanable

To disinfect spray a 4:1 ratio water/bleach mixture on the fabric and allow to linger for the time specified by the Centers for Disease Control and Prevention.

Thoroughly rinse with water and pat dry.

Approved Cleaners

This list represents some of the most common options available and is not intended to be comprehensive.

- 3M Cleaner #25 Quat Cleaner
- 3M HB Quat Disinfectant Concentrate
- Cavicide Spray
- Cavicide Wipes
- Citrace Hospital Germicide



Cleaning Guide

Approved Cleaners

This list represents some of the most common options available and is not intended to be comprehensive.

- Isopropyl Alcohol (1:1 water to agent solution)
- PDI Sani Cloth HB
- PDI Sani Cloth Plus
- PDI Sani Hands ALC
- PDI Super Sani Cloth
- Virox Accel PREvention RTU Wipes
- Virox Oxivir Five 16 (16:1 water to agent dilution)
- Virox Oxivir TB
- Virox Rescue
- Virox RTU

The cleaning recommendations above are a guide to help in the maintenance of Momentum Textiles fabrics. They are supplied without warranty, representation or inducement of any kind, including, but not limited to, the implied warranties of merchantability and fitness for particular use or purpose. Momentum Textiles can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Momentum be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. Users must read the product specifications and determine appropriateness for specific applications. All label instructions on their use and precautions should be followed.